

1978-1996 GM B-Body Extended Length Adjustable Rear Upper Control Arms Poly Ends Item # 3620



Note: Extended length upper control arms are preset to 5/8" longer than the factory control arm. Once the control arms are installed on the vehicle the length may be changed for the application.

1. Jack up rear of vehicle to a good working height, make sure both rear wheels are off the ground. Place (2) jack stands under the frame. **Do not Support by rear axle.** Place jack under the rear end center and place slight upward tension on the rear end.
2. Install control arms one side at a time, removing both control arms at once will allow rear axle to shift forward making the install more difficult.
3. Locate driver's side upper control arm. Using 18mm wrenches/socket remove both front and rear control arm bolts, remove control arm from vehicle. If control seems difficult to remove, use jack to move the rear end in up and down movements to help ease removal. **Note:** If you are installing new rear end housing bushings, this procedure should be completed now. A torch is recommended to ease removal of old bushings.
4. Locate a new control arm. Please note control arms are assembly and shipped pre-set to stock control arm length. Install control arm into place. Do not tighten bolts yet, the vehicle's weight must be on the rear axle before tightening to prevent bushing preload.
5. Repeat steps 3 and 4 on passenger side.
6. Jack up vehicle by rear axle, remove jack stands from frame and placed under rear. Release the jack and let the vehicle weight rest on the jack stands.
7. Tighten all (4) mounting bolts. Recommended torque spec on upper control arms is 72 ft lbs. **Note:** Check jam nuts OFTEN for tightness, over time these items may work loose and need retightened

Setting Pinion Angle

UMI Performance presets the control arms to stock length. However please double check these adjustments. An angle finder is needed to measure the drive line angle of the vehicle.

How to Check the Current Pinion Angle- To check the current pinion angle the vehicle must be level with the suspension loaded. Place the angle finder on the drive shaft and record the angle. Now place the angle finder on the bottom of the rear end or rear end yoke, record this angle as well. To achieve true pinion angle you must add the two measurements. For example if the drive shaft measures 0 degrees and the torque arm mount measures -1 degrees you have -1 degrees of pinion angle. We have found the best settings for a street driven car are: 1-2 degrees downward.

How to Adjust the Pinion Angle- Using UMI Performance's on-car adjusters, adjusting pinion angle is simple. Loosen both jam nuts on the adjuster of each control arm. Use a 1" wrench and adjust each adjuster equally. It won't take much to get a degree. Once pinion angle is set tighten **all** jam nuts tight. Check all bolts and jam nuts often. Pinion angle is to be set with suspension loaded and vehicle level.

Thank you for putting your trust in a UMI Performance product!



509 Hemlock St
Philipsburg, PA 16866
Ph- 814.343.6315 Fax- 814.343.6318

Installation Instructions

support@umiperformance.com
www.umiperformance.com

DISCLAIMER OF WARRANTY

THE PURCHASER ACCEPTS ALL RESPONSIBILITY FOR THE FINAL USE OF THE PRODUCTS PURCHASED AND SHALL HOLD UMI PERFORMANCE INCORPORATED AND ITS REPRESENTATIVES HARMLESS IN ANY LEGAL PROCEEDING ARISING FROM THE USE OF SUCH PRODUCTS.

UMI PERFORMANCE INCORPORATED DOES NOT WARRANT, GUARANTEE, OR MAKE ANY REPRESENTATION REGARDING THE USE, OR THE RESULT OF THE USE OF ANY PERFORMANCE PRODUCT MANUFACTURED OR DISTRIBUTED BY UMI PERFORMANCE INCORPORATED. PURCHASER ASSUMES THE ENTIRE RISK AS THE RESULT AND PERFORMANCE OBTAINED FROM THE INSTALLATION AND USE OF SAID PERFORMANCE PRODUCTS. UMI PERFORMANCE INCORPORATED ASSUMES NO RESPONSIBILITY FOR AND HEREBY DISCLAIMS ALL WARRANTIES, ORAL OR WRITTEN, EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION, THE WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE.

ALL PARTS ARE WARRANTED TO BE FREE OF DEFECT AT THE TIME OF PURCHASE. WARRANTY IS ONLY EXTENDED TO REPLACEMENT OF PARTS FROM UMI PERFORMANCE INCORPORATED AND DOES NOT COVER LABOR, TOWING OR ANY OTHER DIRECT OR INDIRECT COST. UMI PERFORMANCE INCORPORATED IS NOT RESPONSIBLE FOR ANY CONSEQUENTIAL DAMAGE, EXPENSE OR INJURY ARISING FROM THE USE, MISUSE OR IMPROPER INSTALLATION OF ANY PRODUCT MANUFACTURED AND/OR SOLD BY UMI PERFORMANCE INCORPORATED.

Item # 3620

78-96 GM B-Body Adj. Upper Control Arms

UMI Performance Inc.
Made in Pennsylvania, USA

Thank you for putting your trust in a UMI Performance product!

Page 2 of 2